



Assembly


Stressless® Emily




Scan me for instruction




STRESSLESS® EMILY INDEX




STRESSLESS® EMILY
1 Seat Power/Dummy Page 5




STRESSLESS® EMILY
Corner Page 9




STRESSLESS® EMILY
End Module Page 13
Center Module Page 14





STRESSLESS® EMILY
LongSeat Medium Page 15



STRESSLESS® EMILY
LongSeat Large Page 20




STRESSLESS® EMILY
1 Seat Angled Page 25




STRESSLESS® EMILY
Battery Pack Page 30


STRESSLESS® EMILY MODULES




1s
w/arm left




1s
wo/arms




1s
w/arm right




Angled module
w/arm left



Angled module
wo/arms



Angled module
w/arm right



Corner




1s Power
w/arm left




1s Power
wo/arms




1s Power
w/arm right




Longseat
(M) arm left




Longseat
(M) arm right



Longseat
(L) arm left




Longseat
(L) arm right



Center
module




End module
left



End module
right



Arm Steel



Arm Wide




Arm Wood

POWER SUPPLY PLACEMENT





- EN CAUTION: Maximum seats per Power supply unit = 3.
Battery placement only on modules with Power supply.
- NO OBS: Maksimalt antall motoriserte seter per strømforsyning = 3.
Batteri skal bare kobles til moduler med strømforsyning.
- SV VARNING: Maximalt antal motoriserade platser per strömförsörjningsenhet = 3.
Batteri placering endast på moduler med strömförsörjning.
- DK OBS: Maksimalt antal motoriseret sæder pr. strømforsyning er 3.
Batteri skal kun tilkobles moduler med strømforsyning.
- FIN HUOM: Moottoroitujen istuimien enimmäismäärä virtalähdettä kohti = 3.
Akun saa kytkeä vain moduuleihin, joissa on virtalähde.
- DE ACHTUNG: Maximal 3 Sitzelemente pro Netzteil!
Platzierung des Akkus nur bei Modulen mit Netzteil.
- NL LET OP: Maximaal aantal Power zitplaatsen per transformator = 3.
Installatie van de batterij alleen op met transformator uitgeruste module(s).
- FR ATTENTION : Nombre maximum de places Power par transformateur = 3.
Installation de la batterie uniquement sur le(s) module(s) équipé(s) de transformateur.
- IT ATTENZIONE: Numero massimo di posti Power per trasformatore = 3.
Installazione della batteria solo su moduli dotati di trasformatore.
- ES OJO: Número máximo de plazas Power (motorizadas) por transformador = 3.
Instalación de la batería solo en módulos equipados con transformadores.
- PT CUIDADO: Máximo de lugares por unidade de fonte de alimentação = 3.
Colocação da bateria apenas em módulos com fonte de alimentação.
- JA 注意: 電源モーター1個あたりの接続可能最大座席数 = 3。
バッテリーは電動モーターモジュールにのみ設置可。
- ZH 注意: 每个电源装置最多支持3个椅位; 电池仅内置于带有电源装置的沙发模块中。
- KR 주의: 전원 공급 장치당 최대 시트 수 = 3 전원 공급 장치가 있는 모듈에만 배터리 배치
- TW 注意: 每個電源裝置的最大席位數 = 3。電池只能放置在帶電源的模組上。
- IN सावधान: प्रतपावर सप्लाय युनिट अर्धकितम सीटे = 3। बैटरी को केवल बजिली की आपूर्ति वाले मॉड्यूल पर लगाए।




→ = Power Connections

STRESSLESS® EMILY 1 SEAT POWER / DUMMY




1997498





If battery, assemble battery pack on modules with power supply


3




4




5




6



7





8





Stressless® Emily - 8

STRESSLESS® EMILY CORNER








 Ø 4.2 cm
 8 cm/3.15 inch
 6x 1997508

1




Stressless® Emily - 9


If battery, assemble battery pack on modules with power supply



6



7



STRESSLESS® EMILY END MODULE





Chrome 1997394
Black 1997395




2x 1997016




12.5 cm/4.92 inch
2x 1997826




STRESSLESS® EMILY STEEL



12.5 cm/4.92 inch
2x 19978XX




12.5 cm/4.92 inch
2x 1997826




STRESSLESS® EMILY WOOD



12.5 cm/4.92 inch
2x 1997820





12.5 cm/4.92 inch
2x 1997826




STRESSLESS® EMILY WIDE

STRESSLESS® EMILY CENTER MODULE


 Ø 4.2 cm
 12.5 cm/4.92 inch
 4x 1997826



STRESSLESS® EMILY LONG SEAT MEDIUM








 Ø 4.2 cm
 8 cm/3.15 inch
 6x 1997508



4x 990004315



4x 990000859






STRESSLESS® EMILY LONGSEAT MEDIUM LEG PLACEMENT






Chrome 1997394
Black 1997395






4x 1997016



STRESSLESS® EMILY STEEL





STRESSLESS® EMILY WOOD






STRESSLESS® EMILY WIDE

If battery, assemble battery pack on modules with power supply

5




6







7




8




9




10



STRESSLESS® EMILY LONG SEAT LARGE




 Ø 4.2 cm
 8 cm/3.15 inch
 6x 1997508




3x 990004315




3x 990000859


1



2



3



STRESSLESS® EMILY LONGSEAT LARGE LEG PLACEMENT





Chrome 75012616
 Black 75012615




4x 1997016





Ø 4.2 cm
 8 cm/3.15 inch
 2x 1997508




STRESSLESS® EMILY STEEL



 Ø 4.2 cm
 12.5 cm/4.92 inch
 2x 19978XX



 Ø 4.2 cm
 8 cm/3.15 inch
 2x 1997508



STRESSLESS® EMILY WOOD





 Ø 6 cm
 12.5 cm/4.92 inch
 2x 1997820


 Ø 4.2 cm
 8 cm/3.15 inch
 2x 1997508




STRESSLESS® EMILY WIDE

If battery, assemble battery pack on modules with power supply






1997498





2x 1997543




4x 1997721




10






STRESSLESS® EMILY 1 SEAT ANGLED




 Ø 4.2 cm
 8 cm/3.15 inch
 4x 1997508



 2x 1997543


 4x 1997721




If battery, assemble battery pack on modules with power supply


4




5





6





7



8




9



Stressless® Emily - 28

10




Stressless® Emily - 29


BATTERY PACK

1997548


Available for all modules with Power supply unit.




1997337



990005980




1997390




75015615





1



2



WARNING





STRESSLESS.COM

Ekornes AS, Industrivegen 1, N-6222 Ikkornes
Tel.: (+47) 70 25 52 00
E-mail: office.no@ekornes.com