



**Assembly**  
Stressless® Sofa  
with Plus™ System

*Stressless*



## STRESSLESS® SOFA INDEX




Round Legs  
Page 3




Coned Legs  
Page 4



Steel Hoop  
Page 6




STRESSLESS® SOFA  
Medium Corner Page 7




STRESSLESS® SOFA  
Sector to Sofa Page 8

## DISASSEMBLY




STRESSLESS® SOFA  
Armrest Page 10

## STRESSLESS® SOFA STEEL / WOODEN LEGS, ROUND




Round Legs


### Sofa




### Medium Corner







### Sector







### Sector Arm 11




## STRESSLESS® SOFA CONED LEGS




## STRESSLESS® SOFA CONED LEGS CORNER



## STRESSLESS® SOFA STEEL HOOP




## STRESSLESS® SOFA MEDIUM CORNER



# STRESSLESS® SOFA SECTOR TO SOFA




1997721




1997674


1



2




3




# STRESSLESS® SOFA DISASSEMBLY - ARMREST


1




2



3



4



Stressless®

STRESSLESS.COM

Ekornes AS, Industrivegen 1, N-6222 Ikorntes

Tel.: (+47) 70 25 52 00

E-mail: office.no@ekornes.com